

Materials List

for “Extended Roof” and Aluminum Heat Reflectors for Heat Protection on Nest Boxes.

Steve Garr

Birds-I-View

Jefferson City, MO www.birds-i-view.biz



Extended Roof

- Thin wood approx 18 x 24 inches
- 6 spacers 1/2 inch (spacers can be made from rigid tubing or pieces of wood)
- 6 screws 1 to 1 1/2 inches long (the length of the screws depends on the thickness of the roof).
- The extra roof needs to be installed where it blocks most of the afternoon sun and has air flow between the two roofs.

Aluminum Reflective panels



- Aluminum side panels are attached with screws and spacers. Cut the aluminum sheets to match the sides, use four spacers per side to allow air flow between the side and the aluminum.
- Aluminum siding cut to fit
- 4 spacers 1/2 inches long per side
- 4 screws 1 to 1 1/2 inch long

Provided by **Birds-I-View** 573-638-BIRD(2473)

Jefferson City, MO www.birds-i-view.biz